

The Lowest-Cost,  
Most-Simplified Outside  
Lift On The Market!



**Bruno Model  
ASL-225**



**Fits 1.25 in/3.2 cm Hitch Receiver!**

## OPTIONAL BRUNO POW'RPAC



- ◆ Easy to use!
- ◆ Convenient!
- ◆ Works in most minivans, SUVs, station wagons & sedans!

The complete, independent power supply for your automotive lift!

**Pow'rPac easily installs in your vehicle – just plug into the vehicle's power outlet!**

- ◆ The Bruno Out-Sider® Micro Vehicle Lift, Model ASL-225, is the lightest-weight exterior vehicle lift designed to transport today's popular travel scooters!
- ◆ It's designed with fewer parts than any other outside lift and it's easy to install – it takes less than one hour!
- ◆ Lowest-profile design minimizes rear vision obstruction.
- ◆ Industry-leading 145 lb/65.9 kg lifting capacity.
- ◆ The Out-Sider Micro installs on vehicles using a Class I sport or Class II receiver hitch with 12 in/30.5 cm or less ground-to-hitch receiver clearance.
- ◆ The gas spring assist provides easy "fold/unfold" of the lift platform. The safety latch prevents unintentional lowering of the lift platform.
- ◆ The convenient control arm lets you operate the lift from a safe distance. Road and laboratory tested by a certified testing facility.
- ◆ Exclusive "lift mast angle adjustment" allows the installer to nest the Out-Sider® Micro tight against the rear of the vehicle.
- ◆ An ultra-strength strap system is used to secure the scooter to the platform. It's easy to use and can be operated with one hand!
- ◆ Expert installation and complete, after sale service is provided by Bruno's worldwide network of dealers.

◆ Only Bruno has over 20 different interior/exterior scooter, wheelchair and powerchair lifts for nearly any sedan, crossover, minivan, SUV, full-size van, or pickup truck.

◆ All Bruno lifts are eligible for reimbursement under the terms of Mobility Programs offered by GM, Honda, Hyundai, Subaru, Chrysler (Dodge, Jeep), Ford, Toyota, Lexus, Volvo and Volkswagen.

# Using the *Bruno Out-Sider® Micro* is easy!



1 Insert key, turn ON and lift tab.



2 Lift lever and fold down platform.



3 Unhook belt and loosen Velcro®\*.



4 Press switch to lower platform.



5 Roll scooter on platform, press switch to raise and secure with belt.



6 Lower lever, secure belt to Velcro®\*, turn key to OFF and remove key.

\*Velcro® is a registered trademark of Velcro Industries B.V.

**Represented By:**

  
for your independence

Bruno Independent Living Aids, Inc., 1780 Executive Drive  
P.O. Box 84, Oconomowoc, WI 53066

[www.bruno.com](http://www.bruno.com)